


TORQUE SUPPORT



TYPES OF TORQUE SUPPORT

ARTICLE	A	B	C	D	Ra	Ri	αB	αS
SB-A065 55X75X20	65	90	45	28	R75	R55	70	50
SB-A80 70X90X20	80	110	54	34	R90	R70	70	50
SB-A110 100X120X20	110	130	87	31	R120	R100	60	40